



TECHNICKÉ VLASTNOSTI



Rozměry výrobku: Velikost: 112 mm*91 mm*138,5 mm
Materiály: Materiál: ABS/PP/Silikon/PVC
Hmotnost: 250gr
Příkon: 250 g: DC5V/0,5A
Frekvence: 108 kHz
Jmenovitý výkon: 1,5-2W
Nabíjecí proud: 0,5A
Kapacita baterie: 1200mAh
Doba nabíjení: 3H
Provozní doba: 3 hodiny: 4H
Kapacita nádržky na vodu: cca 200 ml
Rychlost postřiku: cca 40 ml/H

OBALOVÉ PŘÍSLUŠENSTVÍ

- 1 Humybot
- 1 USB kabel
- 1 uživatelská příručka

POPIS PRODUKTU

- ① Vestavěná malá panenka
- ② Otočte a otevřete základní vodu
- ③ Světla
- ④ Světelný klíč
- ⑤ Tlačítko pro stříkání vody
- ⑥ Nabíjecí port USB-C



POKYNY K POUŽITÍ

Sprejový klíč: Klepnutím zapnete režim stříkání a klepnutím přepínáte mezi režimy stříkání (3sekundový interval cyklu), opětovným krátkým stisknutím sprej vypnete.

Tlačítko světla: Klepnutím zapnete světlo, dalším klepnutím nastavíte režim dechového světla, dalším klepnutím světlo vypnete.

Světelný indikátor: Červený indikátor je při nabíjení trvale zapnutý a při plném nabití je červený indikátor vypnutý, při práci svítí bílý indikátor.

Pracovní doba: Automatické vypnutí po 4 hodinách (spuštění časování posledním provozním tlačítkem).

BEZPEČNOSTNÍ OPATŘENÍ PRO POUŽITÍ

- Před přidáním vody odpojte napájecí zdroj. Nepoužívejte jej při zapnutém napájení, aby nedošlo k zkratu způsobenému přetečením vody.
- Pokud je na povrchu rozprašovače voda, bude ovlivněn účinek rozprašování. K okamžitému nasátí vody použijte čisté papírové utěrky. Používejte čistou vodu z vodovodu nebo minerální vodu. Nepoužívejte čistou nebo destilovanou vodu. Nedotýkejte se rozprašovací tablety rukama nebo předměty.
- Doporučuje se, aby byl vatový tampon poprvé důkladně namočen. Absorpce vody bez navlhčení t přibližně několik minut.
- Nepoužívejte tento výrobek ve vlhkém prostředí (například v koupelně), kontakt s vodou může způsobit selhání nebo poškození výrobku.
- S tímto výrobkem neklepejte ani na něj nepadejte, opakované klepání může způsobit vnitřní poškození.
- Pokud tento výrobek delší dobu nepoužíváte, neskladujte jej na místě s vysokou teplotou a vlhkost
- Tento výrobek nerozebírejte, neměňte ani neopravujte.
- Nenabíjejte výrobek nad stanovené napětí.
- Po nabití výrobku se ujistěte, že jste včas vytáhli nabíjecí kabel.
- Nevkládejte výrobek do ohně, abyste předešli riziku výbuchu.
- Nedotýkejte se tohoto výrobku mokřima rukama ani jej nepoužívejte.
- Výrobek uchovávejte mimo dosah dětí.
- Tento výrobek používejte při pokojové teplotě (0-40 °C).
- Nenabíjejte výrobek na povrch hořlavých předmětů, jako jsou koberce a přikrývky.
- Tento výrobek není hračka, kupující a jeho uživatelé prosím dohlížejte a usměrňujte příslušné děti, aby si jej nepletly s hračkou.
- Nedoporučuje se pro děti mladší 14 let.
- Opatrná likvidace: Dodržujte prosím místní předpisy o recyklaci elektronického odpadu a nevyhazujte powerbanku svévolně, abyste zabránili dopadu na životní prostředí.

OPATŘENÍ A ZABEZPEČENÍ

1. K nabíjení výrobku používejte adaptér 5V-1A (není součástí dodávky), nižší nebo vyšší napětí než uvedené může poškodit baterii a obvod.
2. Neumísťujte výrobek do blízkosti ohně nebo silného magnetického pole.
3. Obal obsahuje důležité informace. Uchovejte si je pro budoucí použití.
4. Tento výrobek je určen pouze pro vnitřní použití.
5. Tento výrobek má vestavěnou dobíjecí lithiovou baterii, při jejím nepoužívání neznečišťujte životní prostředí a snažte se ji co nejvíce třdit a recyklovat.
6. NEBEZPEČÍ UDUŠENÍ Malé části, není určeno pro děti do 3 let.
7. Pokud jsou zjevně poškozené části, přestaňte jej používat a držte jej mimo dosah dětí. Nedovolte dětem hrát si s rozpadlým, poškozeným nebo deformovaným výrobkem, aby nedošlo k náhodnému spolknutí, udušení a jinému nebezpečí.
8. Nikdy neumísťujte toto zařízení na jiné elektrické zařízení.
9. Chraňte napájecí kabel před chozením nebo skřípnutím, zejména u zástrček, zásuvek a v místě, k vystupuje z přístroje.
10. Zkontrolujte, zda napájecí napětí odpovídá napětí uvedenému na štítku na zadní straně přístroje. Při odpojování ze zásuvky vždy vytáhněte zástrčku ze zásuvky. Nikdy netahejte za kabel. Před zapojením do zásuvky se ujistěte, že jsou provedena všechna ostatní připojení.
10. Používejte pouze zařízení/příslušenství doporučené výrobcem.
11. Toto zařízení by mělo být používáno v mírném prostředí, mimo dosah přímého slunečního světla otevřeného ohně nebo tepla, ohříváčů, sporáků nebo jiných zařízení (včetně zesilovačů), která vytváí teplo. Zařízení neinstalujte v blízkosti zdrojů tepla.
12. Baterie nesmí být vystaveny nadměrnému teplu, například slunečnímu záření, ohni apod.
13. Za horka nebo při delším nepoužívání odpojte toto zařízení od sítě



ENGLISH

TECHNICAL CHARACTERISTICS

Product dimensions: 112mm*91mm*138,5mm

Materials: ABS/PP/Silicone/PVC

Weight: 250gr

Input power: DC5V/0.5A

Frequency: 108kHz

Rated power: 1,5-2W

Charging current: 0,5A

Battery capacity: 1200mAh

Charging time: 3H

Operating time: 4H

Water tank capacity: about 200ml



Spray Rate: about 40ml/H

PACKAGING ACCESSORIES

- 1 Humybot
- 1 USB cable
- 1 user manual

PRODUCT DESCRIPTION

- ① Built-in small doll
- ② Turn and open the base water
- ③ Lights
- ④ Light key
- ⑤ Water spray key
- ⑥ Charging USB-C port



INSTRUCTIONS OF USE

Spray key: Tap to turn ON the spray mode and tap to switch between spray modes (3 second cycle interval), short press again to turn OFF the spray.

Light key: Tap to turn ON the light, tap again for breath light mode, tap again to turn OFF the lights.

Indicator light: The red indicator is steady ON when charging, and the red indicator is OFF when fully charged, the white indicator light is on when working.

Working time: Automatic shutdown after 4 hours (start timing with the last operation button).

PRECAUTIONS OF USE

- Please unplug the power supply before adding water. Do not operate with power on to prevent short circuit caused by water overflow.
- If there is water on the surface of the atomizer, the spray effect will be affected. Please use clean paper towels to soak up water immediately. Please use clean tap water or mineral water. Do not use pure or distilled water. Do not touch the spray tablet with hands or objects.
- It is recommended that the cotton swab be thoroughly soaked for the first time. It takes about a few minutes to absorb water without wetting.
- Do not use this product in a humid environment (such as a bathroom), contact with water may cause product failure or damage.
- Do not knock or fall this product, repeated knocking may cause internal damage.
- If you do not use this product for a long time, do not store it in a place with high temperature and humidity.
- Please do not disassemble, change or repair this product.
- Do not charge the product over the specified voltage.
- When the product is charged, please make sure to pull out the charging cable in time.
- Do not put the product into the fire to avoid the risk of explosion.
- Do not touch or use this product with wet hands.
- Keep the product out of reach of children.
- Use this product at room temperature (0-40°C).
- Do not charge the product on the surface of flammable objects such as carpets and quilts.
- This product is not a toy product, the purchaser and its users please supervise and guide the relevant children to mistake it for a toy.
- Not recommended for children under 14 years of age.
- Careful disposal: Please comply with local e-waste recycling regulations, and do not discard the power bank at will to avoid environmental impact.

MEASURE AND SECURITY

1. Please use 5V-1A adaptor to charge the product (not included), lower or higher than these voltage can harm the battery and circuit.
2. Do not put the product near fire or strong magnetic field.
3. The packing contains important information. Retain for future reference.
4. This product is for indoor use only.
5. This product has built-in rechargeable lithium battery, please do not pollute the environment when disused and try to classify and recycle as much as possible.
6. CHOKING HAZARD Small parts, not for children under 3 years.
7. If there are any obvious damaged parts, please stop using it and keep it away from children. Do not let children play with disintegrated, damaged or deformed product to avoid accidental swallowing, suffocation and other hazards.
8. Never place this device on top of other electrical equipment.
9. Protect the power cord from being walked on or pinched, especially at plugs, convenience receptacles and the point where they exit from the unit. Check that the supply voltage corresponds to the voltage indicated on the plate at the rear of the unit. When unplugging, always remove the plug from the socket. Never pull on the cord. Before plugging in, ensure that all other connections have been made.
10. Use only equipment/accessories recommended by the manufacturer.
11. This device should be used in a temperate environment, away from direct sunlight, open flames or heat, heaters, stoves or any other appliance (including amplifiers) that generates heat. Do not install near heat sources.
12. The batteries must not be exposed to excessive heat, such as sunlight, fire, etc.
13. Unplug this device during lightning storms or when unused for long periods of time.